






757-842-6497
WWW.JLOSC.COM

J&L 3.0 Oil Separator, Driver Side (2015-2022 EcoBoost Mustang) #3029D Installation Instructions

Please review complete instructions prior to installing.


**It is recommended to use a lift or place the front of the car on jack stands. **

1	<p>Remove engine cover (two 10mm bolts, two 8mm bolts). Remove the stock line from the PCV Valve under intake manifold on the engine block to the connection behind the throttle body.</p> <p>Lower fitting</p>  <p>Upper fitting</p> 
2	<p>Use the supplied bolt and nut to mount J&L bracket to the tab on the driver side shock tower.</p> 
3	<p>Use the supplied screws to mount the J&L Separator assembly to the J&L bracket routing the "O" hose ("O" Side of can) down toward the engine mount to connect to the PCV, and the T hose ("C" Side of can) under the intake for the fitting behind the throttle body.</p>

From above, route the "C" hose under the throttle body and on to the fitting then push the connection locking tab.



From under, route "O" hose to PCV connection on the engine block



4



To properly clean the filter in the Oil Separator, spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles. Thank you for your business. If you have any questions, please e-mail info@JLosc.com or call 757-842-6497. Our hours are Monday-Friday. 8:00am – 4:30pm Eastern Time.

J&L Oil Separator co. Lifetime Satisfaction Guarantee. We want you to be a J&L customer for life! Your new J&L product is warranted to be free from defects in materials and workmanship for the life of the *original retail purchaser*, subject to the limitations contained in our warranty found here. www.JLosc.com/warranty We guarantee workmanship and even a pathway to discounted upgrades for substantially improved items.

Return Policy: All returns will be subject to a 10%-25% restocking fee. Please visit www.JLosc.com for complete return policy.

Disclaimer: J&L Oil Separator co. makes no warranties whatsoever, expressed, or implied, oral or written to any purchasers, except the warranty above. J&L Oil Separator co. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by J&L Oil Separator co. agree to hold harmless and indemnify J&L Oil Separator co. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to J&L Oil Separator co. for any claims arising out of use of its products.