




**757-842-6497**  
**WWW.JLOSC.COM**


**J&L Oil Separator, Passenger Side  
(2021-2022 Ford Bronco 2.7L EcoBoost)  
#3073P**

**Installation Instructions**

**Install video available at our website [www.JLosc.com](http://www.JLosc.com) Search: 3073P and click videos.  
Please review complete instructions prior to installing.**

Step#	
<b>1</b>	<b>Verify you have all of the following parts included in the kit:</b> (1) J&L Oil Separator (1) J&L Mounting Bracket, (2) Fine Thread Machine Screws, (1) M6 Mounting bolt
<b>2</b>	<b>Gather all of the following tools needed for the installation:</b> 10mm socket and ratchet and Phillips screwdriver.
<b>3</b>	Mount J&L Oil separator to J&L bracket with supplied screws, align logos for proper orientation. Locate and remove Factory PCV line, push/pull blue tab away from fitting to release.
<b>4</b>	

Locate threaded hole on intake manifold and use supplied bolt to mount J&L Oil separator and bracket to manifold. **Do not tighten the bolt yet.**





5

Connect short hose with 45 degree fitting onto intake manifold fitting, connect the longer hose with the 90 degree fitting to the PCV valve on the valve cover. **TIP:** The quick connections are all adjustable in the end of the hoses, if the fitting isn't at an optimum angle, twist the fitting until it is. The hoses can also twist on the J&L Oil separator connections for adjustment.

6

Once hoses are connected, tighten bracket mounting bolt. The oil separator mounting is offset to allow clearance for optional can reservoir extension (Part #'s EXT-B & EXT-C).





To properly clean the filter in the Oil Separator, spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles.

Thank you for your business. If you have any questions, please e-mail [info@JLosc.com](mailto:info@JLosc.com) or call 757-842-6497. Our hours are Monday-Friday. 8:00am – 5:00pm Eastern Time.

**J&L Oil Separator co. Lifetime Satisfaction Guarantee. We want you to be a J&L customer for life!** Your new J&L product is warranted to be free from defects in materials and workmanship for the life of the *original retail purchaser*, subject to the limitations contained in our warranty found here. [www.JLosc.com/warranty](http://www.JLosc.com/warranty)

We guarantee workmanship and even a pathway to discounted upgrades for substantially improved items.

**Return Policy:** All returns will be subject to a 10%-25% restocking fee. Please visit [www.JLosc.com](http://www.JLosc.com) for complete return policy.

**Disclaimer:** J&L Oil Separator co. makes no warranties whatsoever, expressed, or implied, oral or written to any purchasers, except the warranty above. J&L Oil Separator co. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by J&L Oil Separator co. agree to hold harmless and indemnify J&L Oil Separator co. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to J&L Oil Separator co. for any claims arising out of use of its products.