




757-842-6497
WWW.JLOSC.COM

J&L 3.0 Oil Separator
(2020-2023 Buick Encore GX 1.3L Turbo; 2021-2023 Chevy Trailblazer 1.3L Turbo Driver Side)
#3090D

Install video available on our website www.JLosc.com
Search: 3090D and click videos


Please review complete instructions prior to installing.

| | |
|----------|---|
| 1 | Verify you have all of the following parts included in the kit: (1) J&L Oil Separator with hoses, (1) J&L Mounting bracket, (2) M4 screws, (1) M6x1.0 Bolt |
| 2 | Gather all of the following tools needed for the installation: T30 Torx, 10mm socket, extension, ratchet, Phillips screwdriver, small pick tool or flat screwdriver light oil/grease and Q-tip. |
| 3 | <p>Remove factory engine cover, by unscrewing the T30 torx bolt and oil fill cap.</p> <p>Locate factory PCV line going from the valve cover to the turbo.</p>  |

To remove the hose from the connections (we highly recommend watching the video for the greatest detail) there are 6 "teeth" that grab the connection. You have to use your pick tool to gently raise the clips over the barbed fitting they are being held by. You will need to raise 2-3 of them and then you should be able to wiggle the connection off by wiggling it back and forth while pulling upward. **Take your time, this requires patience!**



Disconnect the smaller breather line running from the center of the valve cover to the intake tube. To release these fittings, press the larger grey button inward and pull away from the connection.




5

With this hose removed it will allow you to pivot the PCV line towards the back of the engine to get better access to the fitting clips on the turbo. You can spin the line on the fittings to relieve pressure from the line too. Work the connection on the turbo off the same way as the valve cover.



6

| | |
|----|--|
| 7 | Reinstall small breather line you removed, and you can now reinstall the engine cover you removed in step #1 |
| 8 | <p>Mount J&L Bracket to J&L Oil Separator, by aligning the logos and using the supplied screws.</p> <p>Lubricate the O-rings inside the J&L quick connect fittings with light grease or oil, this will help the new fittings slide into place easily.</p> |
| 9 | <p>Mount J&L oil separator assembly to threaded brass insert on valve cover with the J&L supplied bolt. Do not completely tighten the bolt yet.</p>  |
| 10 | <p>Connect hose with straight fitting to the valve cover connection and connect hose with 45 degree fitting to the Turbo.</p> <p>Once hoses are connected, tighten bracket mounting bolt the rest of the way.</p> <p>NOTE: If the quick connect fittings are not facing the correct direction you can move them by twisting them! They may be stiff to initially break free but they will rotate!</p> |



Oil separator collection varies, we recommend checking the oil separator after 1000 miles of driving to get an idea of how fast your vehicle will fill it!

To properly clean the filter in the Oil Separator, spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles.

Thank you for your business. If you have any questions, please e-mail info@JLosc.com or call 757-842-6497. Our hours are Monday-Friday. 8:00am – 4:30pm Eastern Time.

J&L Oil Separator co. Lifetime Satisfaction Guarantee. We want you to be a J&L customer for life! Your new J&L product is warranted to be free from defects in materials and workmanship for the life of the *original retail purchaser*, subject to the limitations contained in our warranty found here. www.JLosc.com/warranty

We guarantee workmanship and even a pathway to discounted upgrades for substantially improved items.

Return Policy: All returns will be subject to a 10%-25% restocking fee. Please visit www.JLosc.com for complete return policy.

Disclaimer: J&L Oil Separator co. makes no warranties whatsoever, expressed, or implied, oral or written to any purchasers, except the warranty above. J&L Oil Separator co. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by J&L Oil Separator co. agree to hold harmless and indemnify J&L Oil Separator co. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to J&L Oil Separator co. for any claims arising out of use of its products.